


SELECTION CRITERIA

- Fresh water use
- Direct acting
- Actuation by pressure
- 150 PSI water pressure rating
- Flanged end connections
- 3-Way configuration
- 2" & 2-1/2" sizes
- 225 PSI proof pressure

CONSTRUCTION DETAILS

- Brass & Stainless Steel internals
- Buna-N diaphragms & seals
- Body material: See Table II
- Flange: See Table II



Reference Metrex drawing 900P-FL-3W

*NOTE: Normally closed valves open on pressure increase, normally open valves close on pressure increase.

VALVE SIZING CHART

VALVE PART NUMBER	VALVE SIZE	C _v	VALVE DIMENSIONS				
			A	C	F	E	L
90_P-200-FL_-3W	2"	26	4-15/16"	1.93"	1.93"	5-31/32"	3-5/8"
90_P-250-FL_-3W	2-1/2"	37	5-15/16"	2-1/2"	2-1/2"	6-3/8"	4-1/8"

ORDERING INFORMATION

- Use the valve sizing chart on the preceding page, tables, and charts below to determine the complete part number.

BASIC PART NO.: 90 P - - FL -3W

TABLE I — BELLOWS OPTIONS — VALVE SIZING CHART — TABLE II — VALVE CONFIGURATION

BELLOWS OPTIONS

- The optional ammonia actuator is designated by an "A" after the P.

Example: 900PA-200FL1-3W

The optional 1/4" male SAE flare fitting for refrigerant pressure connection is designated by an "F" after the P. The 1/4" SAE flare fitting replaces the 36" long capillary tube with 1/4" SAE flare nut connection.

Example: 901PF-200FL1-3W.

VALVE FLOW DATA





TABLE I

ASSEMBLY NUMBER	CRACK POINT ADJ. RANGE	PRESS. RISE FOR FULL OPEN
901P	25 to 150, for R-12	35 PSI
902P	80 to 210, for R-22	43 PSI
903P	150 to 250 PSI	50 PSI

TABLE II

ASSEMBLY NUMBER	MATERIAL	FLANGE SPECIFICATION	DESIGN PRESS.	PROOF PRESS.	FLANGE DIMENSIONS				
					N	H	B	D	T
200-FL1-	CAST IRON	ANSI B16.1 CLASS 125 LB.	150 PSI	225 PSI	4	0.75"	4.75"	6.00"	0.50"
200-FL2-	BRONZE	ANSI B16.24 CLASS 150 LB.	150 PSI	225 PSI	4	0.75"	4.75"	6.00"	0.50"
250-FL1-	CAST IRON	ANSI B16.1 CLASS 125 LB.	150 PSI	225 PSI	4	0.75"	5.50"	7.00"	0.69"
250-FL2-	BRONZE	ANSI B16.24 CLASS 150 LB.	150 PSI	225 PSI	4	0.75"	5.50"	7.00"	0.56"


VALVE CONFIGURATION



3-WAY HEAD PRESSURE REGULATOR TYPICAL APPLICATION

PAGE 3 OF 3

- Typically used to modulate the cooling water through a condenser in response to a pressure signal from the condenser. Refrigerant head pressure is maintained over a wide range of operating conditions for a maximum system operating efficiency.



INSTALLATION INSTRUCTIONS

- Valves can be mounted in any position without affecting performance. However, for ease of adjustment consider the accessibility of the adjusting screw.
- Connect the incoming water line to the valve inlet. Direction of water flow (see drawing) is indicated by the arrow cast on the side of the valve body.
- Connect capillary tube (1/4" flare nut) to refrigerant head pressure connection on condenser.

GENERAL DESCRIPTION

- The 900 series valves are direct acting, modulating water regulating valves utilizing a diaphragm construction to give a smooth, well balanced action. The pressure-balanced design and low frictional co-efficient of the diaphragm assure fast response to changes in refrigerant pressure and protection against both gradual and sudden water pressure changes. All sliding parts and adjustment springs are isolated from the water flow by the leak proof diaphragms.

ADJUSTMENT

- All valves in 2" and 2-1/2" sizes are multi-range valves applicable to both R-12 and R-22 service (see Table I). The refrigerant pressure at which the valve begins to open can be adjusted from (see Table I). A 35-50 PSI increase of pressure (depending on range option) is required to open the valve fully.

To adjust condensing head pressure, use the adjusting screw on top of the spring housing. Turn counter clockwise to raise the opening point (raise head pressure). Turn clockwise to lower the opening point (lower head pressure).

MANUAL OVERRIDE

- All valves may be manually flushed by inserting a screwdriver in openings at opposite sides of the spring housing and lifting the lower spring plate to open the valve. The valve adjustment is not affected by manual flushing.

