

WCCW65-SE


2-WAY DIRECT ACTING HIGH REFRIGERANT PRESSURE HIGH WATER PRESSURE REGULATING VALVE

SELECTION CRITERIA

- Fresh water use
- Direct acting
- Patented 650 PSI rated actuator
- Open on pressure increase
- For R410a refrigerant applications
- Screwed end connections NPT
- 2-Way configuration
- 3/8" thru 1" sizes
- 350 PSI water pressure standard
- Available water pressure to 500 PSI

PAGE 1 OF 3

CONSTRUCTION DETAILS



All dimensions are in inches

VALVE SIZING CHART & PRESSURE RATING ____

VALVE PART NUMBER	PIPE SIZE	c _v	Α
WCCW65-3050SE	3/8"	2.2	4.38
WCCW65-3060SE	1/2"	2.6	4.38
WCCW65-3070SE	3/4"	4.5	4.38
WCCW65-3080SE	1"	6.0	4.93

PRESSURE RATING				
PRESSURE RATING	STANDARD	Н	EH	
DESIGN PRESSURE	350 PSI	400 PSI	500 PSI	
PROOF PREESURE	525 PSI	600 PSI	750 PSI	

METREX VALVE CORP. ENGINEERED CONTROL SOLUTIONS FOR HVAC

REFRIGERATION
MARINE
NUCLEAR
505 S. Vermont Ave., Glendora, CA 91741, USA (800) 266-4027 Fax: (626) 335-1514 www.metrexvalve.com
Data subject to change without notice.




WCCW65-SE

2-WAY DIRECT ACTING HIGH REFRIGERANT PRESSURE HIGH WATER PRESSURE REGULATING VALVE

PAGE 2 OF 3

ORDERING INFORMATION .

 Use the valve sizing chart on the preceding page, tables, and charts below to determine the complete part number.



EXAMPLE:	• "3070" = 3/4" pipe size
WCCW65-30701H-SE	• "1" = 160-340 range
	• "H" = 400 PSI water pressure

PRESSURE RANGE ADJUSTMENT ____

> The refrigerant pressure range which the valve begins to open can be adjusted per table II. An approximate increase of refrigerant pressure (span) per Table II is required to open the valve fully.

TABLE II				
SET POINT RANGE	ADJUSTMENT	SPAN		
1	160-340	60		
2	TBD	TBD		

All pressures are PSIG




(with valve full open) 45 1' 40 FLOW RATE IN GALLONS PER MINUTE 35 3/4" 30 25 20 1/2" 3/8" 15 10 5 0 2 6 8 10 12 14 16 18 20 22 24 26 28 30 32 34 36 38 40 42 44 46 48 50 0 4 DIFFERENTIAL PRESSURE: PRESSURE DROP ACROSS VALVE (PSID)

VALVE FLOW DATA

2-WAY HEAD PRESSURE REGULATOR TYPICAL APPLICATION

• Typically used to modulate the cooling water through a condenser in response to a pressure signal from the condenser. Refrigerant head pressure is maintained over a wide range of operating conditions for a maximum system operating efficiency.



METREX VALVE CORP. ENGINEERED CONTROL SOLUTIONS FOR HVAC

REFRIGERATION
MARINE
NUCLEAR
505 S. Vermont Ave., Glendora, CA 91741, USA (800) 266-4027 Fax: (626) 335-1514 www.metrexvalve.com
Data subject to change without notice



WCCW65-SE 2-WAY DIRECT ACTING HIGH REFRIGERANT PRESSURE HIGH WATER PRESSURE REGULATING VALVE

PAGE 3 OF 3

INSTALLATION INSTRUCTIONS ____

- 1) Valves can be mounted in any position without affecting performance. However, for ease of adjustment consider the accessibility of the adjusting screw.
- 2) Connect the incoming water line to the valve inlet. Direction of water flow is indicated by the arrow cast on the side of the valve body.
- 3) Connect 1/4" male flare fitting on valve actuator to refrigerant head pressure connection on condenser. Use 1/4" copper refrigerant tubing, capillary tubing or other suitable tubing with 1/4" flare nut connection. Tubing not included with valve. Maximum tightening torque on flare nut is 15 in-lbs.
- 4) See Metrex datasheet 50M-366 for available capillary assemblies for connecting the valve.
- 5) Do not disassemble actuator. There are no user serviceable parts inside the actuator.

GENERAL DESCRIPTION ____

The WCCW65 series valves are high water pressure, direct acting, modulating water regulating valves. All water
pressure boundaries are o-ring sealed for leak-proof, set & forget reliability. The WCCW65 series is rated at 650
PSI refrigerant pressure for R410a service.

Adjustment _____

 All valve sizes are multi-range valves applicable to various refrigerants. The refrigerant pressure at which the valve begins to open can be adjusted as shown in Table II. An approximate increase in refrigerant pressure is required to fully open the valve is also listed in Table II.

To increase the actuating refrigerant head pressure, insert a pin or hex key into the adjustment nut and turn counter-clockwise. To lower actuating refrigerant head pressure, turn adjustment nut clockwise.